SUMP/SEWAGE PUMP

Check Valves

1030-0181 PRO SUMP PUMP CHECK VALVE

- Sump pump check valve connects with 1-1/4 x 1-1/2 in slip x slip union.
- Prevents back flow for efficient pump operation.
- Includes 4 clamps and 2 boots.
- · Can be installed vertically or horizontally.



1030-0242 PRO QUIET SUMP PUMP CHECK VALVE

- Sump pump check valve connects to 1-1/2 in pipe.
- Prevents back flow for efficient pump operation.
- Reduces pump noise.
- Can be installed vertically or horizontally.



1030-0242

1030-0250 PRO SEWAGE PUMP CHECK VALVE

- Sewage pump check valve connects to 2 in pipe.
- Prevents back flow for efficient pump operation.
- Includes 2 clamps and 1 boot.
- Full port flapper design creates positive seal.
- Includes union.



1030-0250

	DIMENSIONS	
PART NO.	W IN	H IN
1030-0181	3-1/2	9
1030-0242	3-3/8	10-3/4
1030-0250	4	9-3/4